

STAINLESS STEEL ACCESSORIES

70" MIDROOF SLEEPER SKIRT – COLUMBIA MODEL – REAR MOUNT EXHAUST

INSTALLATION INSTRUCTIONS

1. Remove plastic coating from tabs and top flange of sleeper skirt. Attach supplied brackets (as per diagram, using supplied 1/4" bolts, nuts and washers), leaving them snug so they can be adjusted. Make sure to center them in slots, and stand brackets "straight up".
2. Holding sleeper skirt flush with the outside of the sleeper skin/panel, and flush with front corner of sleeper, use an ink marker to trace through the slots in the brackets onto the sleeper/underside frame rail.
3. Remove sleeper skirt, and drill 3/16" holes through the center of the marked slots into the frame rail.
4. Move sleeper skirt back into position, and install using the supplied #14 screws through the brackets into the frame rail (do not completely tighten).
5. Adjust the sleeper skirt into desired position flush with outside sleeper skin/panel, and lined up with holes in rear of cab skirt. Tighten all bolts.
6. Attach front of sleeper skirt to rear of cab skirt using supplied 1/4" bolts, nuts and washers.
7. Remove plastic coating, and connect wiring harness to cab skirt/truck wire system (if applicable) as per truck manufacturers specs. Clean with glass cleaner, if necessary.

