

STAINLESS STEEL ACCESSORIES

70" MIDROOF SLEEPER SKIRT – COLUMBIA MODEL - SIDE MOUNT EXHAUST

INSTALLATION INSTRUCTIONS

* INSTALL EXTENDER SKIRT BEFORE ATTEMPTING TO INSTALL SLEEPER SKIRTS *

1. Remove plastic coating from tabs and top flange of sleeper skirt. Attach supplied brackets (as per diagram, using supplied 1/4" bolts, nuts and washers), leaving them snug so they can be adjusted. Make sure to center them in slots, and stand brackets "straight up".
2. Holding sleeper skirt flush with the outside of the sleeper skin/panel, align the holes with the holes in the extender skirt, then use an ink marker to trace through the slots in the brackets onto the sleeper/underside frame rail.
3. Remove sleeper skirt, and drill 3/16" holes through the center of the marked slots into the frame rail.
4. Move sleeper skirt back into position, and install using the supplied #14 screws through the brackets into the frame rail (do not completely tighten).
5. Adjust the sleeper skirt into desired position flush with outside sleeper skin/panel, and lined up with holes in front of extender skirt. Tighten all bolts.
6. Using supplied "Z" shaped brace (and hardware), attach to bottom "tab" on sleeper skirt (located near front of skirt), to sleeper frame rail.
7. Attach sleeper skirt "filler panel" to rear of cab skirt using supplied 1/4" bolts, nuts and washers. As shown below.
8. Using another of the supplied brackets, attach rear of filler panel to sleeper frame rail (as per steps # 2 + 3).
9. Remove plastic coating, and connect wiring harness to cab skirt/truck wire system (if applicable) as per truck manufacturers specs. Clean with glass cleaner, if necessary.

