

## **Stainless Steel Accessories**

### **REAR SLEEPER WINDOW SUNVISOR**

#### **INSTALLATION INSTRUCTIONS**

1. Following 3M taping instructions, thoroughly clean area between rear window rubber molding and roof cap.
2. Hold window visor in desired position, align bolting flanges next to rubber molding and mark holes.
3. Using 1/8" drill bit, drill holes through exterior aluminum skin, into sleeper frame member.
4. Apply a generous amount of silicone in screw holes.
5. Remove 2-sided tape protective coating.
6. Attach window visor carefully re-aligning screw holes before adhering taped portion to sleeper.
7. Apply pressure to tape area insuring proper adhesion.
8. Apply supplied hardware.