


## Stainless Steel Accessories

TRIM, FENDER GUTTER STRIPS 388, 389

### INSTALLATION INSTRUCTIONS

1. Loosen front fender support bracket until the gap between bracket and fender is sufficient to allow the trim to slide down into the gap.
2. Slide the front (wider) edge of trim underneath the front fender support bracket. Slide down approximately 1/2" past edge of the fender support bracket.
3. Roll the trim over the fender gutter. Ensure that the trim is rolled to match the contour of the fender gutter and that the side edge is flush against the side of the hood. The back (thinner) edge of the trim should sit flush against, or very close to rear bottom edge of fender gutter.
4. Adjust the positioning of trim if necessary to achieve ideal fit.
5. When trim is in the ideal position, mark the truck through the hole in trim for later drilling. Also mark a line on the front edge of trim that corresponds to the edge of the front fender support bracket. This line will serve as a guide for later installation.
6. Remove trim from truck.
7. Carefully drill Ø3/16" hole through previously marked hole.
8. Remove backing of tape from trim.
9. Slide the front (wider) edge of trim underneath the front fender support bracket, using previously marked line as a guide for how far to insert the trim.
10. Roll the trim over the fender gutter. Ensure that the trim is rolled to match contour of the fender gutter and that the side edge is flush against the side of the hood. Also ensure that the tape is secure against the gutter. Continue to roll towards the back and the hole on the trim should come to line up with the Ø3/16" drilled hole.
11. Remove protective plastic coating from trim.
12. Fasten using supplied hardware and tighten front fender bracket support bracket.

**Driver**



**Passenger**



**Front of Truck→**