

## Stainless Steel Accessories

### FENDER GUARD 367

#### INSTALLATION INSTRUCTIONS

1. Remove plastic from around bolt holes.
2. Line up edges of tabs of bracket with bottom edge of fender.
3. Ensure there is approximately  $\frac{1}{4}$ " gap between side of bracket and side of hood.
4. Mark holes on fender which correspond to the holes on tabs of bracket.
5. Drill through marked holes with  $\text{Ø}.281$ " drill bit.
6. Open hood.
7. Attached bracket to fender with supplied  $\frac{1}{4}$ " hardware.
8. Attach fender guard to bracket with supplied 10-32 hardware.

