

## Stainless Steel Accessories

### FENDER GUARDS, PETERBILT 367 SET FORWARD AXLE

#### INSTALLATION INSTRUCTIONS

1. Remove plastic from fender guard on areas shown in diagram.
2. Remove factory fender bracket from truck by loosening 4 bolts underneath.
3. Remove bezel from headlight.
4. Insert mounting tabs of fender guard on to two mounting studs of fender bracket.  
(masking of fender brackets may be required to avoid scratching)
5. Place fender guard and fender bracket back on to truck, do not fasten.
6. Ensure proper fit and alignment of fender guard.
7. Mark two holes on to the face of headlight mounting arm (see step 8 for details)
8. Ensure that the top edge of the fender guard will not interfere with headlight bezel.  
Ensure that marked holes will allow for a screw to go through and a washer and locknut to secure on the back side of arm. (space for locknut and washer is restricted)
9. Remove fender bracket and fender guard.
10. Drill through marked holes with 7/32" drill bit.
11. Fasten fender guard and fender bracket with provided hardware and bolts from step 2.
12. Remove remainder of plastic from fender guard.

