

Stainless Steel Accessories

SUNVISOR EXTENSION STRIP

INSTALLATION INSTRUCTIONS

1. Prepare the surface to be taped as per 3M instructions.
2. Remove 3M tape coating.
3. Using extreme caution, align Sunvisor Extension Strip to the lights in the sunvisor.
4. Working from the center out, applying even pressure to Sunvisor Extension Strip to ensure proper adhesion to factory sunvisor.
5. Drill 3/16" holes through end holes.
6. Attach supplied hardware.
7. Remove protective plastic coating.