

## **Stainless Steel Accessories**

**PANEL, REAR FRAME WITH (3) OVAL LIGHT HOLES**

### **INSTALLATION INSTRUCTIONS**

1. Peel plastic from around (2) bolt holes.
2. Remove lights and grommets from the rear frame.
3. Insert only grommets into the stainless steel panel.
4. Attach the panel to the rear frame by inserting the rear flange of grommet through the holes in the rear frame. Ensure that the flange of grommet seals properly.
5. Insert lights into grommets from behind.
6. At this point, (2) holes on the panel should align with (2) holes on rear frame.
7. Fasten panel to rear frame through these (2) holes using supplied hardware.
8. Peel remaining plastic from the stainless and clean with glass cleaner, if necessary.