

Stainless Steel Accessories

GRILLE, SURROUND

INSTALLATION INSTRUCTIONS

1. Remove the grille from truck.
2. Place the side panel such that the bottom edge conforms to the shape of the hood. The panel should sit flush up against front of truck, and the tabs should be up against the side ledge. A slight push may be required to seat the panels into the proper position.
3. When proper alignment is achieved, mark holes and drill $\text{Ø}7/32''$.
4. Fasten side panels with bottom bolt fastened fully and remaining bolts semi tightened.
5. Attach brackets to bug deflector with 10-32 hardware. Fasten semi tight.
6. Place bug deflector on hood, sliding over holes in side panels. Small tabs on deflector should be under the top tabs on side panels (see figure A). Temporarily fasten deflector to side panels.
7. Mark 4 holes through the brackets on to the hood, and mark single hole in front.
8. Set bug deflector aside and drill marked holes $\text{Ø}9/32''$.
9. Fasten all parts. Place nylon washers in between parts and outside of hood (figure B)
10. Remove plastic coating and clean with glass cleaner if necessary.

