

## STAINLESS STEEL ACCESSORIES

DOOR WINDOW SHADE, CORONADO 2011

### INSTALLATION INSTRUCTIONS

1. Remove the mirror from passenger side and reserve the OEM screws for use in step 3.
2. Attach the supplied bracket to the mirror using carriage bolts, nuts and washers (see diagram)
3. Fasten the assembled mirror/bracket to the truck using screws from step 1.
4. Carefully align the stainless steel shade ensuring there is no interference. Attach the shade according to two sided taping instructions enclosed.
5. Repeat for driver side, disregarding steps 1-3 as the driver side has no mirror.

