

STAINLESS STEEL ACCESSORIES

LOWER HOOD PANEL

INSTALLATION INSTRUCTIONS

1. Hold the lower hood panel in place. Trace the hole locations with a pen.
2. Drill 3 holes shown in the diagram below with a #10 (3/16") drill bit. Attach the panel to the hood with 3, #10-32 x 3/4 bolts, nuts and washers.
3. Peel off the plastic coating and clean with glass cleaner if necessary.

