

STAINLESS STEEL ACCESSORIES

9900I & IX FRONT A/C LIGHT BAR

INSTALLATION INSTRUCTIONS

1. Remove protective plastic from the brackets.
2. Assemble the brackets to the light bar as shown below with the supplied #10-32 x 1/2" bolts, nuts and washers. Finger tighten only, as they will need to be adjusted later.
3. Loosen the top two nuts on the air cleaner light bar
4. Slide the light bar assembly underneath the nuts, adjust the position and tighten slightly.
5. Using a pen, trace the mounting holes on the bottom bracket onto the air cleaner.
6. Remove the light bar and set aside.
7. Drill a 7/32" hole in each location marked with pen.
8. Re-attach the light bar and attach the lower bracket to the air cleaner using the supplied #10-32 x 1/2" bolts nuts and washers.
9. Tighten all bolts.
10. Remove the protective plastic coating from the light bar and clean with glass cleaner if necessary.

