

STAINLESS STEEL ACCESSORIES

Door Sill / Scuff Plates

INSTALLATION INSTRUCTIONS

1. Open door.
2. Using rubbing alcohol, thoroughly clean the door sill area and allow it to dry.
3. Hold the supplied scuff plate into desired position. The panel should be centered using the existing body rivets as a guide. Once a satisfactory position is determined, use a piece of masking tape to mark the front edge of the scuff plate onto the truck's door sill.
4. Peel off the red backing tape off the bottom of the scuff plate.
5. While tilting the scuff plate at a slight angle, slide it into position making sure the front edge lines up with the masking tape applied in step #3. When properly installed, the outside folded lip of the scuff plate, should fit nicely over the side of the door sill. Apply pressure to the scuff panel evenly throughout its surface in order to help adhesion.
6. Remove masking tape applied in step #3.
7. Peel off the plastic coating and clean with glass cleaner if necessary.
8. If necessary, gently lift the rubber door seal allowing it to slide over the freshly installed scuff plate.

