

STAINLESS STEEL ACCESSORIES

TRAILER SERVICE BOX

INSTALLATION INSTRUCTIONS

1. Unbolt electrical plugs and airlines from where they are attached to the truck.
2. Place the electrical plugs in appropriate holes in the Trailer Service Box. If only the main plug hole is used, a cover plate for the A.B.S plug is supplied.
3. If the truck has an airline manifold, it will (in most cases) bolt inside the Trailer Service Box. Airline holes and bolt holes on manifold should line up with holes in Trailer Service Box.
4. If the truck has no airline manifold the holes may be attached to holes supplied in Trailer service Box.
5. Once the plugs and airlines have been attached, mount the Trailer Service Box to the frame of the truck using supplied brackets.

