

STAINLESS STEEL ACCESSORIES

W-900 PRE 98' FLAT GLASS EXTENDED SUNVISOR

INSTALLATION INSTRUCTIONS

1. Leave all bolts semi-loose until the last step.
2. **DO NOT REMOVE** plastic coating until the last step, to prevent scratches.
3. Apply silicone caulking into the roof bolt holes before fastening the bolts.
4. Remove factory stainless Sunvisor, and roof brackets.
5. Install the longer center bracket (using the factory bolts), onto the existing factory bolt holes on the roof.
6. Mount the 2 outer brackets using the existing upper bolt holes in the roof. The lower bolt hole must be drilled through the roof (it is possible the a rivet may be removed to provide a bolt hole in some cases). The lower bolt may now be fastened using the 1/4" x 1" bolt supplied.
7. Once the brackets are mounted, place the visor halves on the brackets (overlapping on the center bracket). Line up the end holes and center the bracket holes with the Sunvisor, and roof holes. Mark the underside of the Sunvisor through the outer bracket holes.
8. Remove Sunvisor halves and drill through the Sunvisor.
9. Replace the Sunvisor on the brackets and use the 10-32 x 1/2" screws, washers, and locknuts supplied, to fasten to the brackets. Use the factory end bolts to fasten to ends.
10. When the Sunvisor is in the desired position, tighten all bolts, and remove protective plastic coating.