

Stainless Steel Accessories

FENDER GUARD 567

INSTALLATION INSTRUCTIONS

1. Remove plastic from around bolt holes.
2. Line up profile of Fender Guard with the body lines of the hood.
3. Transfer hole location onto the fender.
4. Drill through marked holes with 9/32" drill bit. A pre drilled pilot hole is advised.
5. Install supplied 1/4" fasteners. 1/2" nylon spacers will go between the fender and the fender guard.
6. Large washers go on the inside of the wheel well.
7. Tighten remaining fasteners.
8. Peel plastic and wipe with glass cleaner if necessary.

