

Stainless Steel Accessories

UPPER SLEEPER AND CAB TRIM

INSTALLATION INSTRUCTIONS

1. Prepare surfaces to be taped following 3M taping instructions carefully.
2. Do not remove protective plastic coating until trim is completely installed.
3. Remove 3M tape coating.
4. Carefully lay trim piece in desired area and apply equal pressure working from the center out toward the sides.
5. Remove protective plastic coating.