

Stainless Steel Accessories

HEADLIGHT/FENDER GUARD KIT

INSTALLATION INSTRUCTIONS

1. Hold the headlight guard in place beside the headlight. Transfer its mounting hole to the truck's hood.
2. Using a 3/16" drill bit, drill hole at the location marked above.
3. Clean the area on which the guard will be applied to with rubbing alcohol.
4. Peel back enough of the 3M backing tape off the back of the part starting from the center, so that when installed, there will be 1" sticking out from the edge of the part.
5. Loosely secure the part to the truck using the supplied hardware. Once desired position is established, peel the remaining 3M backing tape off and apply firm pressure across the part to help adhesion.
6. Hold fender guard in place and transfer its mounting locations to the hood.
7. Repeat steps #2 through #5.
8. Tighten all fasteners.
9. Peel remaining plastic from the stainless and clean with glass cleaner, if necessary.

