

Stainless Steel Accessories

SUNVISOR, 13.5" BOLTLESS, STD CAB, CURVED WINDSHIELD, PB '87 & UP

INSTALLATION INSTRUCTIONS

1. Remove existing OEM stainless steel sunvisor and set aside end bolts.
2. Remove OEM visor brackets by drilling through huck bolts. 1st use 1/8" drill bit, then follow with 9/32" drill bit.
3. In the interior, remove both storage shelf inserts located on the upper console (4 screws in each).
4. Assemble brackets together using 5/8" long bolts, washers and locknuts. (Fig A)
5. Apply silicone to bracket assembly and attach to the visor halves (Fig A). Allow time for silicone curing and clamp brackets to visor halves to maximize adhesion.
6. Fasten center brackets to the cab as shown in Fig B. Do not tighten fully. Use silicone in holes of cab to create a watertight seal.
7. Fasten visor/bracket assembly to the cab. Do not tighten fully. Use silicone in holes of cab to create a watertight seal.
8. Fasten visor halves to each other with 3/4" long bolts.
9. Fasten visor halves to side of cab using bolts set aside from step 1.
10. Fully tighten remaining fasteners.

