



CAB SKIRT PETERBILT 579

Panelite, Inc. · 275 Industrial Road · Cambridge, ON N3H 4R7 · Phone: 519-884-8555 · Toll Free: 1-800-331-7952 · FAX 519-884-8553 · website: www.panelite.com

Installation Procedure:

- 1) Hold the cab skirt to the inside of the lower door flange to check fit and location.
- 2) Hold the cab skirt to the outside of the door flange in the same location and mark the mounting hole locations.
- 3) Drill 5/16" holes in the locations marked.
- 4) Attach the cab skirt to the inside of the flange using the supplied 1/4-20 hardware.