

INSTALLATION PROCEDURE:

1. Clean the area where the new Intake Shroud will be mounted.
2. Cover the approximate area with tape or some other protective coating to prevent scratching the hood during installation.
3. Hold the part up to the approximate location and verify that it is level, and that it will clear all obstacles. Mark hole locations (see below).
4. Drill the holes with a 1/4" drill bit.
5. Remove protective coating or tape from part and hood.
6. Attach using the supplied 1.0" long bolts, and securely tighten (some flexing of the part may be necessary to line up holes).
7. Slowly lower the hood, and check for clearance.

