

## STAINLESS STEEL ACCESSORIES

# INTERNATIONAL HX CAB SKIRT

### INSTALLATION INSTRUCTIONS

1. Remove existing skirt.
2. Remove the rear bracket from truck. (Leave front bracket installed)



Figure 1 - Skirt Bracket

3. Fasten cab skirt to front bracket using original hardware removed in step 2.
4. Fasten middle of cab skirt to underside of cab using the hardware removed in step 2.
5. Mark the remaining mounting holes on underside of cab.
6. Remove cab skirt.
7. Using a 5/32 bit, drill locations marked in step 4.
8. Install the cab skirt as in step 2 and 3, using the original hardware.
9. Install screws supplied into drilled holes
10. Tighten all fasteners.
11. Remove protective coating and clean with glass cleaner and soft cloth, if required.