

**\*\*IMPORTANT \*\***  
**READ BEFORE INSTALLATION**

Clean surface with solvent wash 50/50 (isopropanol-rubbing alcohol & water) using clean, lint free wiping cloths or use the alcohol wipes provided. Allow surface to dry thoroughly.

When dry, use the promoter wipes supplied to wipe down the rubber trim around the windshield.

**RECOMMENDED**

Adhesive surface & part application temperature  
15.6° – 43.3° C or 60°-110°F.

Apply in warm indoor temperatures.

**FIRM PRESSURE MUST BE APPLIED**

To remove all air pockets.

Allow minimum of 12 or more hours for tape to cure to the automotive surface before exposing vehicle to external elements.