

## STAINLESS STEEL ACCESSORIES

# VOLVO VNL - AIR INTAKE SCREEN INSTALLATION INSTRUCTIONS

### INSTALLATION INSTRUCTIONS

1. Remove OEM intake grilles from either side. Some effort may be required as the OEM intake grilles are held/snapped in place with Tinnerman clips across the bottom and tabs across the top; similar to the stainless replacement Air Intake Screens.
2. Carefully remove 2 Tinnerman clips from the OEM plastic intake grilles ensuring to not bend out of shape while doing so as these are required to attach front clips for the new stainless Air Intake Screens.
3. Peel the protective plastic from the two tabs across the top of the Air Intake Screens.
4. Hold Air Intake Screens in place and mark back hole. This will need to be drilled 5/16" for the 8-32 rubber well nut.
5. Mark and drill center bracket. Attach to truck with supplied 3/4" long 10-32 fasteners, washers and nylon locking nuts.
6. Attach front clip to replacement screen leaving screw loose enough for final tightening.
7. Install rubber well nut.
8. Place replacement Air Intake Screen into opening of truck and fasten into place. A small pick like tool may be required to get the plastic anchors into place.

