

## **Stainless Steel Accessories**

### **HEADLIGHT FENDER GUARD**

#### **INSTALLATION INSTRUCTIONS**

1. Place Fender Guard in desired position and mark holes
2. Drill 7/32" holes or 9/64" holes, depending on the mounting holes on the part, in marked area.
3. Thoroughly clean area to be taped as per 3M instructions.
4. Remove 3M tape coating.
5. Carefully aligning bolt holes before attaching taped area to hood.
6. With bolts in place, apply pressure to taped area to ensure proper adhesion.
7. Attach supplied hardware, and tighten.