

Stainless Steel Accessories

LIGHTED UPPER FAIRING TRIM, 5700XE, WESTERN STAR

1. Hold panels in position on the truck. The mid fairing has a notch at the bottom, which indicates the front and identifies driver from passenger side. Using wide masking tape, tape the panels to the truck.
2. Drill the light mounting holes with a 1/8" drill bit and the center wire hole with a 1/2" bit.
3. Use the provided alcohol pads to clean the mounting surface prior to application of the panels.
4. Peel a small section of the backing off each section of tape, so that when the panel is installed, small tabs will be exposed to allow the remainder of the backing to be removed.
5. Place the panels in their desired positions and install each light using the supplied #8x3/8" screws. For the forward light in the extender, use the supplied #8x1" screws. Do not overtighten the 1" screws or it will damage the panel.
6. Peel off the tape backing and apply firm pressure to the panels.
7. Wire the panels as indicated below. Secure loose wires with supplied wire clips or zip ties. Hard wiring to an accessory switch is required.
8. Remove protective plastic and clean with glass cleaner, if necessary.

