

DEF COVER INTERNATIONAL HX

INSTALLATION INSTRUCTIONS

- 1. Hold the new part in the desired location
- 2. Check existing holes on truck and holes and weld nuts should be clean and not damaged
- 3. Attach panels to the truck with the supplied hardware, M8 & 5/16 screws, washers and locknuts
- 4. Tighten all screws
- 5. Peel all remaining plastic, and clean with glass cleaner as necessary

