

Installation Procedure :

1. Using rubbing alcohol, thoroughly clean the under headlight hood area and allow it to dry.
2. Peel off a 2" long section of the 3M red backing tape from the flat end of the supplied fender guard and leave it sticking out from the bottom.
3. Line up the fender guard by tucking it under the headlight bezel and making sure the bottom edge of the guard is flush with the bottom of the hood. Start applying pressure from the inside flat end. As you work your way to the outside curved end, progressively peel off the remaining 3M red backing tape. When properly installed, the fender guard should follow the contour of the bottom and side of the hood.
4. Using a #10 drill bit, drill a through hole using the fender guard hole as a guide.
5. Install supplied truss head screw, washer and nylon lock nut.
6. Peel off protective plastic coating off the fender guard.
7. Tighten bezel screws back up.
8. Clean with glass cleaner if necessary.

