

****IMPORTANT ****
READ BEFORE INSTALLATION

Clean surface with solvent wash 50/50 (isopropanol-rubbing alcohol & water) using clean, lint free wiping cloths or use the alcohol wipes provided. Allow surface to dry thoroughly.

When dry, use the promoter wipes supplied to wipe down the rubber trim around the windshield.

RECOMMENDED

Adhesive surface & part application temperature
15.6° – 43.3° C or 60°-110°F.
Apply in warm indoor temperatures.

FIRM PRESSURE MUST BE APPLIED

To remove all air pockets.

Allow minimum of 12 or more hours for tape to cure to the automotive surface before exposing vehicle to external elements.

****IMPORTANT ****
LIRE AVANT L'INSTALLATION

Nettoyer la surface avec un solvant 50/50 (Alcool à friction Isopropylique et eau) Utiliser des chiffons d'essuyage propres et non pelucheux. Laisser sécher la surface complètement.

Lorsque c'est sec, utilisez les lingettes fournies pour essuyer le caoutchouc autour du pare-brise.

Températures recommandées

pour l'application des surfaces adhésives et pièces
15.6 – 43.3 C ou 60 – 110F.
Appliqué à des températures d'intérieur.

Une pression ferme doit être appliquée
pour éliminer toute poches d'air,

Attendre au moins 12 heures ou plus pour que le ruban durcisse à la surface avant d'exposer le véhicule à des éléments externes.