

## STAINLESS STEEL ACCESSORIES

# 26" SLEEPER EXTENDER SKIRT – COLUMBIA MODEL

### INSTALLATION INSTRUCTIONS

1. Remove plastic coating from areas of extender skirt that will be mounted behind the extender.
2. Hold the extender skirt in the position indicated in diagram. Using a pen, trace the 5 mounting slots on the extender skirt onto the extender.
3. Remove extender skirt, and drill 7/32" holes through the center of the marked slots through the extender.
4. Move extender skirt back into position, and install using the supplied #10 screws, washers and locknuts (do not completely tighten).
5. Adjust the sleeper extender skirt into desired position - flush with the bottom of the sleeper skirt, and lined up with holes in rear of sleeper skirt.
6. Attach front of extender skirt to rear of sleeper skirt using supplied #10 screws, nuts and washers.
7. Tighten all hardware.
8. Remove plastic coating, and connect wiring harness to sleeper skirt/truck wire system (if applicable) as per truck manufacturers specs. Clean with glass cleaner if necessary.

