

STAINLESS STEEL ACCESSORIES

ARGOSY REAR VENT TRIM

INSTALLATION INSTRUCTIONS

1. Peel back 1" of tape on each strip and fold over outside face, so that when the grille is installed, the tape will be easy to pull off.
2. Apply silicone to the base of the opening, where the bottom of the grille will contact.



Silicone this area

3. Install grille and center in opening
4. Using a small hook tool, apply pressure in areas where tape is installed.
5. Peel protective plastic and allow tape to cure for 24 hours in a dry, warm environment.