

Stainless Steel Accessories

SUNVISOR, STANDARD CAB 14", PB 389 PRIDE AND CLASS REPLACEMENT

INSTALLATION INSTRUCTIONS

1. Remove OEM visor panels and brackets, retain fasteners.
2. Enlarge holes in roof brackets with 9/32" drill bit (see diagram).
3. Fasten aftermarket brackets to roof brackets with provided bolts, washers and nuts.
4. Fasten aftermarket visor halves to brackets with fasteners retained from step 1.
5. Fasten visor halves together with provided bolts, washers and nuts.

