

REAR CENTER FAIRING TRIM, WESTERN STAR 5700XE

INSTALLATION INSTRUCTIONS

1. Hold the panel in the desired position and mark the hole locations on the truck fairing.
2. Drill a ¼" hole in each marked location.
3. Clean area where the panel will be installed with supplied alcohol wipes.
4. Peel 3M tape enough so that the plastic sticks out from the part and is easy to remove, when the panel is installed.
5. Remove protective plastic from around mounting holes.
6. Attach the panel to the truck using the supplied carriage bolts, nylon spacers placed between the panel and the truck, flat washers and nylon locknut on the inside of the fairing.
7. Peel 3M tape and apply firm pressure to panel to secure.
8. Remove protective plastic and clean with glass cleaner, if necessary.