

Panelite, Inc. · 275 Industrial Road · Cambridge, ON N3H 4R7 · Phone: 519-884-8555 · Toll Free: 1-877-884-8555 · FAX 519-884-8553 · website: www.panelite.com

INSTALLATION PROCEDURE:

1. Disassemble number 3rd and 5th lights from parts if assembled
2. Loosen the side nuts on the air cleaner
3. Slide the light bar assembly underneath the nuts, adjust the position and tighten through obround holes
4. Connect 2 lights and attach to main body with the original hardware, #6X1/2 screws
5. Install chromed bezels
6. Remove the protective plastic coating from the light bar and clean with glass cleaner if necessary.

