

Stainless Steel Accessories

COWL PANEL

INSTALLATION INSTRUCTIONS

1. Remove factory cowl panel and top bracket from truck if necessary.
2. Hold stainless steel cowl panel in desired position with top bolting flange against underside of cab.
3. Mark the bolt holes on the aluminum underside of cab.
4. Before drilling the 1/8" OR 5/32" holes, make sure the hood will not hit the cowl panel when mounted.
5. After holes have been drilled, bolt the panel in place using the supplied #14 x 1" hex head washer sheet metal screw.
6. Use the factory lower bracket and hardware to secure the bottom of the stainless steel cowl panel.
7. Once all the hardware is tight, remove plastic coating.