

Stainless Steel Accessories

FENDER GUARD

INSTALLATION INSTRUCTIONS

1. Place the fender guard against the fender with the bottom lip on the part, below the bottom lip of the fender. The guard's edges will be pointing outwards from the truck.
2. Align the fender guard in the position desired and mark out the 3 holes with a pen.
3. Set the fender guard aside and drill 3, 7/32" holes in the locations marked.
4. Assemble the fender guard to the fender using 2, #10-32 x 1-1/2" pan head bolts in the bottom 2 holes, and 1, #10-32 x 3" pan head bolt through the top hole. Place a nylon standoff between the fender and fender guard in each location and 10-32 flatwasher and locknut on the back side of the fender and tighten.
5. Remove protective plastic coating and clean with glass cleaner if necessary.

