

Stainless Steel Accessories

386 CAB SKIRT

INSTALLATION INSTRUCTIONS

1. Remove the panel where the hood latch is mounted.
2. Remove the inner fender panel behind the front wheel (black plastic)
3. Insert the supplied #14 screw/bolts into the rear three 0.220" dia. holes that are located on the underside of the cab. Please refer to "slot" locations in the cab skirt. Do not completely tighten, but leave roughly 1/4" space between the cab surface and the bolt heads.
4. Hold the cab skirt in position (flush with the outer body panel) and mark the front bolt hole position.
5. Drill a 3/16" hole in this location and mount #14 screw/bolt, again leaving space between the cab surface and the bolt head.
6. Remove the protective plastic from the flange of the skirt that mounts under the cab.
7. Mount the cab skirt in the desired position (flush with the body panels) and tighten all of the #14 screws/bolts.
8. Using a drill with a 7/32" drill bit, reach in behind the rear of the skirt and drill a hole through the hole in the cab skirt. – through the cab body panel.
9. Insert the supplied #10/32 x 1/2" screw, nut and washer, then tighten.
10. Attach cab skirt harness to truck harness (if equipped)

