

STAINLESS STEEL ACCESSORIES

CLASSIC SHORT HOOD FENDER GUARD

INSTALLATION INSTRUCTIONS

1. Remove plastic coating from around bolt holes on fender guard.
2. Remove second bolt on grill and use 1/4" x 1" bolt supplied to fasten angle bracket.
*** NOTE: Leave this bolt loose until final step.**
3. Hold fender guard to bottom edge of fender and mark three holes.
4. Drill holes using 3/16" bit. Use 3/16" x 1" screws and locknuts to fasten fender guards with spacers to fender.
5. Turn small brackets to fit flat against backside of fender guard and tighten. Drill 3/16" holes through fender guards in line with holes in bracket and insert 3/16" x 1/2" screw, nut, and fasten.