

STAINLESS STEEL ACCESSORIES

SHROUD, EXHAUST, CLASSIC

INSTALLATION INSTRUCTIONS

1. Remove the (8) bolts holding the factory shroud in place, set bolts aside.
2. Remove the factory shroud from the truck
3. Remove the handle from the factory shroud, set hardware aside.
4. Fasten the handle to the aftermarket shroud using hardware set aside in step 3.
5. Using the hardware provided, fasten the brackets to the straps on the exhaust as shown below. Note: the passenger side is shown, driver side is mirror image.
6. Fasten the aftermarket shroud to the brackets and threaded holes on straps using the bolts set aside in step 1.
7. Remove plastic and clean with glass cleaner if necessary.

