

Stainless Steel Accessories

DOOR WINDOW SHADE, VOLVO VN SERIES

INSTALLATION INSTRUCTIONS

1. Line up the window shade to follow contour of door and mark holes onto door through the notches in the window shade.
2. Set window shades aside and drill through marked holes with $\text{Ø}1/8''$ drill bit.
3. Prepare door mounting surface according to 3m tape instructions provided.
4. Fasten the window shade with screws provided, do not tighten fully.
5. Remove 3M tape and press window shade up against door. Ensure shade follows the door contours properly to ensure proper adhesion.
6. Fully fasten the screws from step 4.

