

## **CAB SKIRT Peterbilt 579**

### **INSTALLATION INSTRUCTIONS:**

1. Hold the cab skirt to the inside of the lower door flange to check fit and location.
2. Hold the cab skirt to the outside of the door flange in the same location and mark the mounting hole locations.
3. Drill 5/16" holes in the locations marked.
4. Attach the cab skirt to the inside of the flange using the supplied 1/4-20 hardware.

## **JUPE DE CABINE Peterbilt 579**

### **INSTALLATION INSTRUCTIONS:**

1. Maintenez la jupe de cabine sur l'intérieur du rebord inférieur de porte pour vérifier l'ajustement et l'emplacement.
2. Maintenez la jupe de cabine à l'extérieur du rebord de la porte au même emplacement et marquez l'emplacement des trous de fixation.
3. Percez des trous de 5/16" aux endroits marqués.
4. Fixez la jupe de cabine à l'intérieur du rebord de porte à l'aide de la quincaillerie 1/4-20 fournie.

## **FALDA DE CABINA Peterbilt 579**

### **INSTRUCCIONES DE INSTALACIÓN:**

1. Sostenga la falda de cabina hacia adentro de la brida de la puerta más baja para chequear ajuste y localización.
2. Sostenga la falda de cabina hacia afuera de la brida de la puerta en la misma localización y marque la localización de los agujeros de montaje.
3. Perfore agujeros de 5/16" en las localizaciones marcadas.
4. Junte la falda de cabina hacia adentro de la brida usando los accesorios de 1/4-20 provistos.