

## SHORT HOOD CAB PANEL 2022+ KENWORTH NEXT GEN T680

### INSTALLATION INSTRUCTIONS:

**NOTE:** If the cab panels are blank then Steps 5 and 7 will be skipped.

1. Peel the plastic film from the flanges but not from the face of the panel.
2. Remove the OEM rocker panel.
  - a. Remove the cowl panel. There are two bolts inside the door and two underneath the hood.
  - b. Remove the rocker panel. There are four bolts inside the door and one that was behind the cowl panel.
3. Hold the cab panel in position against the rocker panel and mark the location of the four mounting holes.
  - a. On the driver side, the rear of the cab panel should be flush with the rear edge of the rocker panel.
  - b. On the passenger side, the rear edge of the cab panel should be 1/16" past the rear edge of the rocker panel.
4. Drill 9/32" holes in the marked locations.
5. Drill an additional hole approximately halfway between the two forwardmost mounting holes for the wiring to run through. A 3/4" step bit works well for this.
6. Install the cab panel using the supplied 1/4" hardware, with the locknuts on the inside of the rocker panel. Use a nylon washer between the cab panel and the rocker panel at the forwardmost mounting hole.
7. Pull the male bullet plugs through the hole drilled in Step 5 and then connect the supplied harness end to it.
8. Reinstall the rocker panel.
9. The supplied 10-32 hardware will be used to secure the transition panel to the cab panel when it is installed.
10. Peel the plastic film and clean with glass cleaner and a soft cloth as needed.