

## **UPPER SLEEPER & CAB TRIM** **Volvo**

### **INSTALLATION INSTRUCTIONS:**

1. Prepare surfaces to be taped following 3M taping instructions carefully.
2. Do not remove protective plastic coating until trim is completely installed.
3. Remove 3M tape coating.
4. Carefully lay trim piece in desired area and apply equal pressure working from the center out toward the sides.
5. Remove protective plastic coating.

## **GARNITURE SUPÉRIEURE DE CABINE ET COMPARTIMENT-COUCHETTE** **Volvo**

### **INSTRUCTIONS D'INSTALLATION:**

1. Préparez les surfaces qui recevront la garniture en suivant attentivement les instructions de 3M.
2. Ne pas retirer la pellicule de protection en plastique jusqu'à ce que la garniture soit complètement installée.
3. Retirez le papier du ruban 3M.
4. Placez soigneusement la garniture sur la zone souhaitée et exercez une pression égale à partir du centre vers les côtés.
5. Retirez la pellicule protectrice en plastique.

## **MOLDURA SUPERIOR PARA CABINA Y DORMITORIO** **Volvo**

### **INSTRUCCIONES DE INSTALACIÓN:**

1. Prepare las superficies para colocar el adhesivo 3M siguiendo las instrucciones cuidadosamente.
2. No quite la cubierta plástica protectora hasta que la moldura está completamente instalada.
3. Quite el protector de la cinta adhesiva 3M.
4. Con cuidado coloque la pieza de moldura en el área deseada y aplique presión pareja desde el centro a los lados.
5. Quite la cubierta plástica protectora