

EXTENDED CAB PANELS KENWORTH W990

INSTALLATION INSTRUCTIONS:

NOTE: While not required, removing the passenger step/DPF cover is recommended to make the install easier.

1. Remove the OEM cab panels & save the hardware as it will be reused.
 - a. If applicable, remove the block heater & transfer it to the new cab panel.
2. Assemble the upper (UBD/P) & lower (LBD/P) brackets together as shown in the diagram below. Do not fully tighten the hardware yet as adjustment will be needed.
3. Temporarily hold the new cab panel in place and locate the nutserts on the bottom of the cab that align with the slotted holes on the bottom flange of the cab panel. Fasten the assembled brackets to the truck with the supplied M6 bolts, flat washers, and lock washers. Do not fully tighten the hardware.
4. Install the cab panel onto the truck, reusing the OEM hardware from Step 1.
5. Use the supplied 1/4-20 truss head screws to fasten the bottom of the cab panel to the brackets installed in Step 3. Blue thread-lock or similar is recommended.
6. Fully tighten the hardware from Step 3.
7. Fully tighten the hardware from Step 2.
8. Reinstall the passenger step/DPF cover (if removed).

