

## Stainless Steel Accessories

### 05+ REAR AIR CLEANER LIGHT BAR

#### INSTALLATION INSTRUCTIONS

1. Remove the factory air cleaner light bar, if existing. Remove the 2, 3/8" mounting bolts
2. Hold the 1/8" thick supplied mounting plate against the truck, so that the 2 center holes (rivet relief cuts) surround the rivets.
3. Using the supplied 3/8" bolts and washers, bolt the plate in place. Do not tighten.
4. Slide the light bar mounting flange under the washer & bolt heads as shown below.
5. Adjust the light bar, so that the face almost touches the hinge, but does not interfere.
6. Connect wiring harness and tighten all bolts.
7. Remove plastic coating (if present) and clean with glass cleaner, if necessary.

