

Stainless Steel Accessories

REAR AIR CLEANER LIGHT BAR

INSTALLATION INSTRUCTIONS

1. Remove the protective plastic coating from the slotted side of the light bars only.
2. If air cleaner is equipped with “Anti-theft bolts” it will be easier to install the Air Cleaner Light Bar if the top “Anti-theft bolts” do not line up with a light hole, exchanged “Anti-theft bolts” with the standard bottom bolts, as the light holes are not very forgiving when lining up the “Anti-theft Key”.
3. Remove the two rear air cleaner mounting strap bolts. These may be equipped with “Anti-theft bolts”, and will require a special key provided by Peterbilt. Using plastic tie straps to hold straps in place is recommended.
4. Insert bolts through the slotted holes in light bar, re-thread into fixed strap threaded holes.
5. Once the Light Bar is in desired position, tighten bolts and remove plastic tie straps. (when applicable)
6. Remove remaining protective plastic coating.

